

API-5kW-VAWT

Installation and Operation Manual

Instructions for installation, testing and maintenance for 5KW vertical axis wind turbines

About the product

This product can be used by in any areas where has good wind resource, such as building roofs in cities, environment favorable buildings, and dependent small power stations in suburbs. It can provide stable and reliable electricity for lighting, household electrical appliances, beacon light, microwave communication, equipment, meters. It is ideal power supply equipment for families and companies.

Major components and working rationale

The whole unit consists of pillar, wind generator, storage batteries and inverter/controller. The Mill is pushed by wind at speed from 4m/s to 25m/s to rotate to make the generator produce power in AC form. Then the power will be changed into DC form by the charging controller to be saved in storage batteries. As last, DC power is changed into standard AC power through the inverter.

Connectivity instructions

Connect the batteries in series-mounting based on different voltages with the wires provided with the storage batteries. Then connect it with the corresponding terminal of the inverter/controller. Make sure all the contacts of the batteries and inverters are well connected. Anode end should be connected with anode end while cathode end should be connected with cathode end.

Installation instructions

1. How to find a good location

The product should be installed in a flat area with good wind resource, without big trees or building around. There should not be any buildings higher than the product within 30-meter area around it.

2. How to set up the foundation

Fix the base onto the concrete foundation according to the Figure of Foundation, and adjust the base to be flat. Curing period for the concrete foundation is 100 hours. Enough space should be given to lift the wind turbine unit. The central point of the generator to the inverter/controller should be less than 13-14 meters.

3. How to assemble the pillar and wind generator

Assemble the pillar and pilot set up


Lift the pillar to the base of the concrete foundation, to place and to the foundation bolts, then tighten all the nuts in turn.

Installation of the windmill

1) Wind turbine main parts. Refer to drawing 1

- 1、Flaps,


- 2、Sustaining arms,
- 3、Pillar,
- 4、Generator
- 5、Brake hub discreteness,
- 6、Main Axis
- 7、Top flange, slotted set screws, keys,
- 8、Bolts, washers, spring washers,
- 9、Bolts, plain washers, spring washers
- 10、Blades,
- 11、Lifting eyes bolts,
- 12、Springs, turn buckles,
- 13、Bolts, nuts and plain washers, spring washers,




Drawing 1

2) Installation process


a) Connect the blades with the sustaining arms, screw tight with bolts(M6X95), bolts(M6X60), plain washer($\Phi 6$)and Locknuts (M6). Refer to drawing 2.



b) Wipe the silica gel onto the two side section of the blades, connect with the flaps and screw tight with bolts(M8X30), plain washer ($\Phi 8$) and spring washer($\Phi 8$). Refer to drawing 3.




c) Connect the blades discreteness with the long sustaining arms by plug-pins, then tight with nuts and insert the split cotter pins into the plug-pins. Refer to drawing 4.



Drawing 4


d) Lift the blades discretely, placing the sustaining arms parallel onto the top and nether flanges, connecting with M10X30 bolts, $\Phi 10$ plain washers, $\Phi 10$ spring washers and M10 locknuts, keeping the blades in uprightness. Refer to Drawing 5.



Drawing 5


e) Hitch the two ends of the springs with the holes of the top and nether flanges, **turn the turn-buckles and tight the**

springs to the end, keeping the stretch of each spring accordant. Refer to Drawing 6.




Drawing 6

f) Screw the lifting eye bolt (M12) into the base, and lift the windmill onto the pillar by crane. Make sure the stability of the windmill in the process of lifting in case of overturn. Connect the base with the pillar, and screw tight with bolt(M16X50), plain washer($\Phi 16$), spring washer($\Phi 16$) and locknuts(M16). Refer to drawing 7.




Drawing 7

Note: All bolt joint points must be coated with thread locking glue. The screws and nuts you received may differ from those in this manual. What you receive is the final standard.
Installation complete, referring to drawing 8 and 9.



Drawing 8



Drawing 9

4 Testing

1. Check all the bolts before the testing to make sure they are all securely tightened.
2. Turn around the mill slightly with hands to check if there is any collision. Fix it there is.
3. For off-grid use, connect all the wires: connect the generator, controller/inverter and the storage batteries with cables provided as shown in Drawing 8. For in-grid use, connect the generator, controller/inverter and grid as shown in Drawing 9.

To avoid danger and accident, installation should not be conducted when there is strong wind.

Instructions on maintenance

1. Appropriate and timely maintenance of the system is directly related to the performance and life cycle of it. Key points are:

- a) Inspect, clean and lubricate all the rotating parts once a year.
- b) Clean, derust and paint all the exposed parts in every two years.
- c) Frequently check the tension of the cables of the pillar. When any of them get loose, they should be fastened promptly.

2. Other reminders:

- a) Inverter/controller should be placed in a dry, ventilated and non-polluted environment. **Read carefully the manual of the controller and the inverter.**
- b) The storage batteries will leak certain amount of caustic gas, so they should be placed in a ventilated area without flames.
- c) It is forbidden to leave anything on the terminals of the storage batteries to prevent short circuits.

Troubleshooting

Problems	Causes	Solutions
Abnormal noise	<ol style="list-style-type: none">1. Fastened parts are getting loose2. Connection between the bearing of the generator and the base is getting loose3. The bearing of the generator has been damaged4. Mill rubs with other parts5. Rotor and stator rubs with each other	<ol style="list-style-type: none">1. Check the loose parts and fasten again2. Find out the exact point and fix it3. Change the bearing4. Inspect and fix it5. Repair the rubbing points
Rotating speed of the mill is obviously decreasing	<ol style="list-style-type: none">1. Rotor and stator rubs with each other2. Short circuit occurred in rotor winding3. The Switch is in the Off position	<ol style="list-style-type: none">1. Disassemble the generator to restore the specification data in the magnet.2. Find out the point with short circuit to peel off and insulate3. Put the switch into On
Output voltage is low	<ol style="list-style-type: none">1. Rotating speed of the generator is low2. Permanent magnet rotor is demagnetized.3. Short circuit exists in the stator winding4. Slip ring in power transfer and joints of output wires are not	<ol style="list-style-type: none">1. Find the causes to restore the normal speed2. Change the rotor3. Find out the point, and paint it to insulate4. Clean the slip ring and joints to decrease contact ring brush

	conducted 5. Low voltage power line too long, wire too slim	5. Shorten the wire or enlarge the wire diameter to decrease lost in transferring
No output currents from the	1. Output wire is broken 2. Stator winding burned and caused broken	1. Find out the point and reconnect 2. disassemble and fix
AC output is, but no DC output	1. DC safety belt broken 2. Output wire is broken 3. Rectifier is damaged	1. Change the safety belt 2. Find out the point and reconnect 3. Change the rectifier
Output capacity of the storage batteries is not enough	1. Output voltage is too low from the generator, or no power 2. Terminals of the storage batteries are acid etching, conductance broken 3. Storage batteries expired	1. Refer to the solutions for Problem 3 2. Clean the joints, fasten the connection and apply protection oil 3. Change the batteries

Warranty statement

1. Warranty period is one years starting from the date in the shipping bills. Warranty Card and shipping bills will be required for warranty services.

2. In the warranty period, any of the below problems occurred due to manufacturing quality, exchange for new parts and reparation is free.

a) With normal use of the product, power generating is abnormal due to rotor stopping working, short circuit in stator, the generator will be replaced.

b) With normal use of the product, brokenness happened on exterior shell of the generator and the base which may affect the performance of the system. The part will be replaced.

c) With normal use of the product, blades that fell over will be replaced.

d) With normal use of the product, because of quality reason, the weight-holding part of the pillar has tip off, it will be replaced or repaired at the option of Aeolus.

3. Aeolus will charge for repair and replacement of parts when warranty does not cover any other problems including those that arise as a result of,

a) Components fall down or damaged because animals bump, bite, push or pull the pillar, cables and other parts.

b) Damages to the blades because stopping the mill in wrong measures, e.g., with a wood pole to stop the blades. Or some parts get broken because of improper operating when the system is running at a high speed.

c) Problems occurred because moving the product or changing the installation methods and locations at one own will.

d) Damages due to force majeure, e.g., earthquake, sand storm, strong hail, hurricane, typhoon, thunder strike, replace and repair will be charged.

Note: Make sure that you install the turbine when the wind speed is under 7m/s.